


HOW TO:

SETUP YOUR FORECADDY FIRMWARE UPDATE KIT



Note: Firmware upgrade 5.0 requires you to use the USB Firmware upgrade device and connect it to your ForeCaddy via the USB to USB extension cable. Firmware upgrade 5.0 does not require you to upgrade the remote control.